

DMMODEL DOMINATOR DIVERSITY
INSTALLATION INSTRUCTIONS



Place the holder in position as shown in figure



Gently slide the module SMA connectors inside the clip pushing towards the middle of the goggles





Keep pushing gently until you are able to slide the connector pins inside the relevant slot. There's no way to misplace pins, just be sure that pins enters correctly. Push down the module to place it completely in position. First time maybe it requires more time but you'll get used in short, it's not difficult

At the end, place the Y connector that way and power both systems with a single battery. If you prefer, you can power the module with a second battery placed on the left side of the goggles, a 2S battery is suggested.

